

IMPORTANT!

**ATTACH GROUND STRAP
FROM CABINET UNDER
WING NUT.**



STD-523